ALUMINUM SINGLE ACTING

MODEL: RAC-1502, RAC-1504, RAC-1506, RAC-1508, RAC-15010

Form. #

sales@bia-tools.com www.bia-tools.com

Not all components of cylinder are replacement items, but are illustrated as a convenient reference of location and position in the assembly sequence.

PARTS ILLUSTRATION



BIA TOOLS

ALUMINUM SINGLE ACTING

MODEL: RAC-1502, RAC-1504, RAC-1506, RAC-1508, RAC-15010

Form. #

sales@bia-tools.com www.bia-tools.com

PARTS LIST

ITEM	DESCRIPTION	QTY	RAC-1502	RAC-1504	RAC-1506	RAC-1508	RAC-15010
1	Cylinder Base	1	BT-RAC1502-01	BT-RAC1504-01	BT-RAC1506-01	BT-RAC1508-01	BT-RAC15010-01
2	Plunger	1	BT-RAC1502-02	BT-RAC1504-02	BT-RAC1506-02	BT-RAC1508-02	BT-RAC15010-02
3	Stop Ring	1	BT-RAC150-03	BT-RAC150-03	BT-RAC150-03	BT-RAC150-03	BT-RAC150-03
4	Saddle (Included #5)	1	BT-RAC150-04	BT-RAC150-04	BT-RAC150-04	BT-RAC150-04	BT-RAC150-04
5	Screw	1	-	-	-	-	-
6	Spring	1	BT-RAC1502-06	BT-RAC1504-06	BT-RAC1506-06	BT-RAC1508-06	BT-RAC15010-06
7	Retainer Screw (Included #8)	1	BT-RAC150-07	BT-RAC150-07	BT-RAC150-07	BT-RAC150-07	BT-RAC150-07
8	Copper Washer	1	-	-	-	-	-
9	Protector Plate (Included #10)	1	BT-RAC150-09	BT-RAC150-09	BT-RAC150-09	BT-RAC150-09	BT-RAC150-09
10	Screw	4	-	-	-	-	-
11	Coupler	1	BT-QCF06	BT-QCF06	BT-QCF06	BT-QCF06	BT-QCF06
12	Piston Seal	1	*	*	*	*	*
13	Piston Wear Ring	2	*	*	*	*	*
14	Rod Wear Ring	1	*	*	*	*	*
15	Rod Wiper	1	*	*	*	*	*
16	Handle (Included #18)	1	BT-RAC150-16	BT-RAC150-16	BT-RAC150-16	BT-RAC150-16	BT-RAC150-16
18	Screw	2	-	-	-	-	-
19	Back Up Ring	1	*	*	*	*	*
20	O-Ring	1	*	*	*	*	*
23	Vent Plug	1	*	*	*	*	*
26	Dust Cap (Not Shown)	1	BT-QCC06	BT-QCC06	BT-QCC06	BT-QCC06	BT-QCC06
*	Repair Kit	1	BT-RAC150-RK	BT-RAC150-RK	BT-RAC150-RK	BT-RAC150-RK	BT-RAC150-RK