ALUMINUM SINGLE ACTING

MODEL: RAC-502, RAC-504, RAC-506, RAC-508, RAC-5010

Form. #

sales@bia-tools.com www.bia-tools.com

Not all components of cylinder are replacement items, but are illustrated as a convenient reference of location and position in the assembly sequence.

PARTS ILLUSTRATION



BIA TOOLS

ALUMINUM SINGLE ACTING

MODEL: RAC-502, RAC-504, RAC-506, RAC-508, RAC-5010

Form. #

sales@bia-tools.com www.bia-tools.com

PARTS LIST

ITEM	DESCRIPTION	QTY	RAC-502	RAC-504	RAC-506	RAC-508	RAC-5010
1	Cylinder Base	1	BT-RAC502-01	BT-RAC504-01	BT-RAC506-01	BT-RAC508-01	BT-RAC5010-01
2	Plunger	1	BT-RAC502-02	BT-RAC504-02	BT-RAC506-02	BT-RAC508-02	BT-RAC5010-02
3	Stop Ring	1	BT-RAC50-03	BT-RAC50-03	BT-RAC50-03	BT-RAC50-03	BT-RAC50-03
4	Saddle (Included #5)	1	BT-RAC50-04	BT-RAC50-04	BT-RAC50-04	BT-RAC50-04	BT-RAC50-04
5	Screw	1	-	-	-	-	-
6	Spring	1	BT-RAC502-06	BT-RAC504-06	BT-RAC506-06	BT-RAC508-06	BT-RAC5010-06
7	Retainer Screw (Included #8)	1	BT-RAC50-07	BT-RAC50-07	BT-RAC50-07	BT-RAC50-07	BT-RAC50-07
8	Copper Washer	1	-	-	-	-	-
9	Protector Plate (Included #10)	1	BT-RAC50-09	BT-RAC50-09	BT-RAC50-09	BT-RAC50-09	BT-RAC50-09
10	Screw	4	-	-	-	-	-
11	Coupler	1	BT-QCF06	BT-QCF06	BT-QCF06	BT-QCF06	BT-QCF06
12	Piston Seal	1	*	*	*	*	*
13	Piston Wear Ring	2	*	*	*	*	*
14	Rod Wear Ring	1	*	*	*	*	*
15	Rod Wiper	1	*	*	*	*	*
16	Handle (Included #18)	1	BT-RAC50-16	BT-RAC50-16	BT-RAC50-16	BT-RAC50-16	BT-RAC50-16
18	Screw	2	-	-	-	-	-
19	Back Up Ring	1	*	*	*	*	*
20	O-Ring	1	*	*	*	*	*
23	Vent Plug	1	*	*	*	*	*
26	Dust Cap (Not Shown)	1	BT-QCC06	BT-QCC06	BT-QCC06	BT-QCC06	BT-QCC06
*	Repair Kit	1	BT-RAC50-RK	BT-RAC50-RK	BT-RAC50-RK	BT-RAC50-RK	BT-RAC50-RK