cascade

Replacement Battery Guide

01. Product Description

PRODUCT: 38021

DESCRIPTION: LED Rechargeable Colour Change Cloud Night Light

02. Battery Details

- Type: Li-Polymer Rechargeable Battery Pack
- Voltage: 3.7V
- Capacity: 700mAh
- Battery Model: 802535
- Quantity: 1
- Expected Charging Cycles: Approx. 300 charge/discharge cycles

03. Replacement Battery

When replacing the battery, only use a replacement battery with identical voltage, capacity and specifications.

- Type: Li-Polymer Rechargeable Battery
- Voltage: 3.7V
- Capacity: 700mAh
- Battery Model: 802535

WARNING! Use of the incorrect battery type may damage the product, reduce performance or create a safety risk, including overheating, fire or battery failure.

04. Battery Safety Information

- DO NOT short-circuit battery terminals.
- DO NOT puncture, crush, or incinerate the battery.
- DO NOT expose the battery to excessive heat or water.
- DO NOT use damaged swollen batteries.
- Keep batteries out of reach of children.

05. Replacement Battery

DO NOT dispose of batteries in household waste. Please recycle batteries through an approved collection and recycling scheme in accordance with your local regulations.

Signed for on the behalf of Cascade Holdings Ltd:

NAME: Lee Pritchard

SIGNATURE:

DATE: 12th October 2026

POSITION: Compliance Manager