iilus

Installation Manual

Accent 100 Trimless Asymmetrical Type 2

100 10 0052--.---

Power	8W
Voltage	240V-AC
Class	III
Ingress Protection	IP20
Cut-Out	Ø130 x 130mm Depth

1



2



3



4



5



6



7

Installation below plasterboard

1 Cut 130mm diameter aperture.

Lorem ipsum

2-3 Adjust recessing kit face to appropriate depth and secure with locking screw located on the back of the housing. Screw recessing kit into plasterboard.

4 Plaster to edge of recessing kit.

5 Plug driver into luminaire and mount in recessing kit by lining up tabs on housing with tabs on recessing kit.

6 Screw facade into recessing kit.

AUSTRALIAN MADE

iilus

Installation Manual

Accent 100 Trimless Asymmetrical Type 2

100 10 0052--.---

Power	8W
Voltage	240V-AC
Class	III
Ingress Protection	IP20
Cut-Out	Ø130 x 130mm Depth

1



2



3



4



5



6



7



Installation above plasterboard

1 Cut 130mm diameter aperture.

2 Adjust recessing kit face to appropriate depth and secure with locking screw located on the back of the housing. Fold back recessing kit mount's flaps.

3 Rotate recessing kit and insert into the aperture.

4 Apply liquid nails to secure recessing kit to plasterboard.

5 Plaster to edge of recessing kit.

6 Plug driver into luminaire and mount in recessing kit by lining up tabs on housing with tabs on recessing kit.

7 Screw facade into recessing kit.

AUSTRALIAN MADE