

F&M introduces the

Adjustable Mullion Threshold Receptacle Assembly

MR-T-AD-95 (or MR-X-AD-95 when threshold not required)

Where pairs of doors require removable mullions, the Adjustable Mullion Threshold Receptacle Assembly provides a flush surface when conditions require that the mullion be removed for a period of time. No trip hazard. No hazard for equipment rolling over the threshold into or out of the building. Smooth transition onto and off the threshold. Meets ADA ½” maximum height requirement. For 2” x 3” removable mullions with radiused corners. Warrantied for the life of the building.

Threshold specifics:

--Extra heavy duty; length as required; 9 1/2” wide; 5/16” thick

Mullion Receptacle specifics:

-- 4” long x 4 1/2” wide with a 2” long x 3” wide x 3/8” thick Adjustable Safety Block in the bottom of the receptacle.



Illustrations 1- 5, left to right: Remove Mullion; Remove Safety Block; Flip Safety Block over; Reinstall Safety Block, providing flush surface for pedestrians and rolling equipment.

**For additional information, contact Howard Wright at
Howard.Wright@whwmktg.com.**

Frame & Mullions LLC ©

problem solvers by design