


EASYRID ELECTRICAL DIAGRAM



- LD1, LD2 : PROGRAMMING LED
- LD3 : 24 Vac
- LD4 : PHOTOCELL (N.C.)
- LD5 : START/STOP (N.A.)

FIGURE 1 : WORKING TIME





FIGURE 2 : AUTOMATIC CLOSURE



REMOTE CONTROL CODES : PUSH P2 UNTIL LD1 ISBLINKIN G, THEN PUSH THE BOTTON ON THE REMOTE CONTROL.


ATTENTION : WHEN ENTERING A CODE ALREADY STORED, THE CODE WILL BE DELETED FROM THE MEMORY OF THE BOARD.

ERASING OF ALL REMOTE CONTROL CODES : PUSH P2 UNTIL LD1 IS BLINKING, THEN PUSH P1 THREE TIMES.

WORKING TIME : TO SET THE WORKING TIME TURN TRIMMER RV1 AS SHOWN IN FIGURE 1.

AUTOMATIC CLOSURE : TO SET THE AUTOMATIC CLOSURE SET TRIMMER RV2 AS SHOW IN FIGURE 2.

NOTE : WHEN THE BOARD IS NOT IN PROGRAMMING MODE, THE BOTTON P1 CAN BE USED AS START/STOP BOTTON.



BAME s.r.l. - Via L. da Vinci, 23 - 46020 SAN GIACOMO SEGNATE (MN) - ITALY

Tel. +39 0376 616 638 - Fax +39 0376 629 456 - <http://www.bame.it> - <http://www.delma.it>

Unità locale: Via Enrico Berlinguer, 6 - 63844 GROTTAZZOLINA (FM) - ITALY

Tel. +39 0734 633 533 - Fax +39 0734 636 895 - e-mail: delma@bame.it - venditedelma@bame.it

WARNINGS!!!

OUR COMPANY, AS MANUFACTURER, CAN NOT BE HELD RESPONSIBLE FOR DAMAGES DUE TO WRONG OR MISSING CONNECTIONS OR DUE TO AN IMPROPER SETTING.

THE SAFETY DEVICES SHOULD BE ALWAYS INSTALLED AND KEPT IN FULL WORKING ORDER.

ONCE TERMINATED THE SYSTEM SETTING, YOU SHOULD PLACE BACK THE CONTAINER ON ITS POSITION, FASTENING TIGHT ITS SCREWS.

OUR COMPANY, AS MANUFACTURER, CAN NOT BE HELD RESPONSIBLE FOR DAMAGES DUE TO IMPROPER USE OF THE DOOR/GATE.

IT IS FORBIDDEN TO REPLACE ANY ELECTRIC, ELECTRONIC OR MECHANIC PART WITH NOT ORIGINAL OUR COMPANY SPARE PARTS.

OUR COMPANY, HAS THE RIGHT TO MODIFY OR CHANGE THE ELECTRONIC BOARDS AND MANUALS, WITHOUT PRIOR NOTICE.

ALWAYS REGULATE ACCURATELY THE TORQUE OF THE MOTORS. AN INCORRECT SETTING OF THE TORQUE, MAY CAUSE DAMAGE TO PEOPLE, ANIMALS OR OBJECTS.

WARRANTY:

Our company devices and accessories are for a period 24 months after production, whose date is printed on each item. Our company will replace or repair its devices, provided that they are returned to our plant. In order to check the actual functioning of the returned pieces, they will remain the property of the manufacturer. The warranty does not include damages due to any incorrect use, such as: non-fulfilment of the instruction detailed for each device, maintenance and repairing carried out without the previous written consent of our company. Moreover, warranty does not cover any damage due to wrong tension supply and any other reason for which the manufacturer cannot be made responsible. Any device returned must be delivered to our company with carriage paid and will be sent back with freight collect. Warranty validity ceases in case of the customer's non-fulfilment of payment. Each device by our company meets the safety regulations in force (UNI 8612). Our company declines all responsibility for the non-observance of the safety rules by part of the installer.

In order to reduce the time spent for repairing, faulty materials sent back to us must be accompanied by the installer's comment about the piece