



- PLACE RE-PN-LO81875 IN HYDRA-BED 3100 ARM AS SHOWN IN DETAIL A
- WITH DB200 SITTING ON THE GROUND, ROTATE HYDRA-BED ARMS TO THE REARWARD POSITION. POSITION TRUCK/HYDRA-BED SO LIFT PINS WILL ENGAGE IN DUMP BOX LIFT BRACKET. GRIP & LOAD DUMP BOX ONTO HYDRA-BED
- WITH DB 200 SITTING COMPLETELY ON HYDRA-BED, INSERT REAR CONTAINING BRACKETS INTO TUBE AND PLACE KEEPER PINS IN APPROPRIATE HOLE.
- TO DUMP LOAD FROM DUMP BOX, PUSH ON THE UNLOAD CONTROL



DB 200 DUMP BOX W/ PN-LO81875 LIFT PINS MOUNTING INSTRUCTIONS

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF TRIPLE
C INC. ANY REPRODUCTION IN PART OR
AS A WHOLE WITHOUT THE WRITTEN
PERMISSION OF TRIPLE C INC. IS PROHIBITED.

DIMENSIONS ARE IN INCHES TOLERANCES: FRACTIONAL $\pm 1/16$ ANGULAR: MACH ± 1 BEND \pm TWO PLACE DECIMAL ± 010 THREE PLACE DECIMAL ± 005	
MATERIAL	--
DO NOT SCALE DRAWING	

NAME	DATE
DRAWN HEATH	1/15/2014
PART #	
ASM #	
COMMENTS: INSTALLATION INSTRUCTION HB3100 W/ DUMP BOX	

P.O. BOX 248,
SABETHA, KS 66534

TRIPLE C
INC.

SIZE	DWG. NO.	REV.
A	90-0502	A
SCALE: 1:30	WEIGHT: --	SHEET 1 OF 1